

RESIBLOCK '22'

APPLICATION GUIDE SUMMARY*

On new projects, ensure paving is sealed with RESIBLOCK '22' simultaneously with pavement construction, on a daily basis. DO NOT WAIT until project is complete.

1. Make sure the surface and **jointing sand** are THOROUGHLY DRY and free from dirt.
2. Ensure that RESIBLOCK '22' is only applied when there is no risk of rain within the next 8 hours.
3. Do not apply in extremes of temperature (below 3°C or above 30°C).
4. Ensure paving is thoroughly swept and that no jointing sand remains in the chamfers of the pavers.
5. Apply to surface using a watering can (with the rose) and remove all surplus with the SQUEEGEE.
6. Accurate application rates are critical to ensure full joint stabilisation (typically 1 litre/2m²).
7. A MINIMUM of 3 hours and a MAXIMUM of 24 hours between the first and second coats. Two coats are recommended to prevent fuel/water infiltration. ONE COAT ONLY on clay pavers.
8. Avoid walking on the sealed area for 3 hours after application and do not drive motor vehicles on the surface for 24 hours.
9. ALWAYS WEAR PROTECTIVE GLOVES AND GOGGLES. NO SMOKING. WEAR A MASK WHEN WORKING IN CONFINED AREAS. Please refer to current MSDS.
10. All uncured spillage's/splashes, and all tools must be cleaned immediately with Resiclean.

**FOR FREE ADVICE TELEPHONE
RESIBLOCK
01268 273344**

* ***This fact sheet is not intended to replace the full application instructions, which must be read prior to application.***