

## **RESIBLOCK RESIECCO**

### **APPLICATION SUMMARY\***

On new projects, ensure paving is sealed with **RESIBLOCK RESIECCO** simultaneously with pavement construction, on a daily basis. **DO NOT WAIT** until project is complete.

1. Make sure the surface and jointing sand are **THOROUGHLY DRY** and free from dirt.
2. Ensure that **RESIBLOCK RESIECCO** is applied when there is no risk of rain within the next 24 hours.
3. Do not apply in extremes of temperature (below 5°C or above 30°C).
4. Ensure paving is thoroughly swept and that no jointing sand remains in the chamfers of the pavers.
5. Stir contents well.
6. Apply to surface using a watering can (with the rose attached) and remove **ALL** surplus with a **RESIBLOCK SQUEEGEE**.
7. Accurate application rates are essential to ensure full joint stabilisation e.g. 100 x 200mm CBP 2m<sup>2</sup>/litre. For other dimensions contact Resiblock's Technical Department.
8. Avoid walking on the sealed area for 2-4 hours after application and do not drive motor vehicles on the surface for approximately 72 hours.

**FOR FREE ADVICE TELEPHONE  
RESIBLOCK  
01268 273344**

***\*This fact sheet is not intended to replace the Full Application instructions, which must be read prior to application.***