

RESIBLOCK ULTRA MATT

APPLICATION GUIDE SUMMARY*

On new projects, ensure paving is sealed with RESIBLOCK *ULTRA MATT* simultaneously with pavement construction, on a daily basis. **DO NOT WAIT** until project is complete.

1. Make sure the surface and **jointing sand** are THOROUGHLY DRY and free from dirt.
2. Ensure that RESIBLOCK *ULTRA MATT* is only applied when there is no risk of rain within the next 8 hours.
3. Do not apply in extremes of temperature (below 5°C or above 30°C).
4. Ensure paving is thoroughly swept and that no jointing sand remains in the chamfers of the pavers.
5. Apply to surface using a watering can (with the rose) and remove all surplus with the SQUEEGEE.
6. Accurate application rates are critical to ensure full joint stabilisation (typically 1 litre/2m²).
7. Wet-cast paving slabs **must** be pre-treated with RESIBLOCK *E.R.* and allowed to thoroughly dry (2 weeks recommended).
8. A MINIMUM of 3 hours and a MAXIMUM of 24 hours between the first and second coats. Two coats are recommended to prevent fuel/water infiltration (but may reduce S.R.V.). ONE COAT ONLY on clay pavers.
9. Avoid walking on the sealed area for 3 hours after application and do not drive motor vehicles on the surface for 24 hours.
10. ALWAYS WEAR PROTECTIVE GLOVES AND GOGGLES. NO SMOKING. WEAR A MASK WHEN WORKING IN CONFINED AREAS. Please refer to current MSDS.
11. All uncured sealant and tools should be cleaned immediately using RESICLEAN.
12. Being aliphatic based it is temperature sensitive, if stored at temperatures below 10°C, the polymer may tend to settle out of the solvent, as such ensure contents of container are thoroughly mixed.

**FOR FREE ADVICE TELEPHONE
RESIBLOCK
01268 273344**

- * *This fact sheet is not intended to replace the full application instructions, which must be read prior to application.*