

## **RESIBLOCK ENVIROFIX**

### **APPLICATION SUMMARY\***

On new projects, ensure paving is sealed with RESIBLOCK ENVIROFIX simultaneously with pavement construction, on a daily basis. DO NOT WAIT until project is complete.

- 1 Ensure the surface and jointing aggregate is reasonably dry and free from sand and fines.
- 2 Ensure that RESIBLOCK ENVIROFIX is only applied when there is no risk of rain within the next 24 hours.
- 3 Do not apply in extremes of temperature (below 5° C and above 30° C)
- 4 Ensure paving is thoroughly swept and that no jointing aggregate remains on the surface of the pavers.
- 5 Stir contents well
- 6 Apply to entire surface using a watering can (with the rose) and remove all surplus with the RESIBLOCK SQUEEGEE.
- 7 RESIBLOCK ENVIROFIX is usually only applied as a 1 coat system. However the joints should be checked (once dry) to ensure adequate bonding of the aggregate. Should the grit appear not to be fully bonded then a 2nd coat should be considered.
- 8 Surface can be immediately opened to foot traffic. Do not drive motor vehicles on the surface until joints are dry and bonded.
- 9 Always wear protective gloves and goggles. Please refer to current MSDS.
- 10 All uncured ENVIROFIX and tools should be cleaned immediately using water and detergent.
- 11 On clay paver systems it is critical to ensure that no excess sealer is left on the surface and a dry Resiblock Squeegee or Resi-roller should be used for this purpose.

**FOR FREE ADVICE TELEPHONE  
RESIBLOCK  
01268 273344**

\* ***This fact sheet is not intended to replace the full application instructions, which must be read prior to application.***