






## RESIBLOCK '22' A.F APPLICATION SUMMARY

- 1 Ensure that steps 1,2,3 & 4 are completed the same day.
- 2 Following final compaction, sweep the area thoroughly to remove surplus sand. Ensure that the jointing sand has been fully removed from the chamfer. Ensure both sand and paver are completely dry.
- 3 RESIBLOCK '22' A.F is not much thicker than water and is easily applied by utilising a watering can with a rose attached. Accurate spread rates are essential e.g. 100 x 200mm Concrete Block Paving (CBP) 2m<sup>2</sup>/litre. For best results fill your watering can with RESIBLOCK '22' A.F, pour out 1 litre evenly over 2m<sup>2</sup>, being a manageable amount to squeegee.
- 4 Having applied Resiblock to the pavers, squeegee off the surface starting at the top and always working towards you. Pull RESIBLOCK '22' A.F off the surface, it will pool in the chamfers/joints and will be absorbed by the kiln dried jointing sand.



# RESIBLOCK '22' A.F

## APPLICATION SUMMARY

On new projects, ensure paving is sealed with RESIBLOCK '22' A.F simultaneously with pavement construction, on a daily basis. **DO NOT WAIT** until project is complete.

1. Make sure the surface and jointing sand are **THOROUGHLY DRY** and free from dirt.
2. Ensure that RESIBLOCK '22' A.F is applied when there is no risk of rain within the next 8 hours.
3. Do not apply in extremes of temperature (below 3<sup>0</sup> C or above 30<sup>0</sup> C).
4. Ensure paving is thoroughly swept and that no jointing sand remains in the chamfers of the pavers.
5. Apply to surface using a watering can (with the rose attached) and remove **ALL** surplus with a RESIBLOCK SQUEEGEE.
6. Accurate application rates are essential to ensure full joint stabilisation e.g. 100 x 200mm CBP 2m<sup>2</sup>/litre. For other dimensions/types of paving contact Resiblock's Technical Department.
7. A **MINIMUM** of 3 hours and a **MAXIMUM** of 24 hours between the first and second coats. Two coats are recommended to prevent fuel/water infiltration. **ONE COAT ONLY ON CLAY PAVERS.**
8. Avoid walking on the sealed area for 3 hours after application and do not drive motor vehicles on the surface for 24 hours.
9. ALWAYS WEAR PROTECTIVE GLOVES AND GOGGLES. NO SMOKING. WEAR A MASK WHEN WORKING IN CONFINED AREAS. Please refer to current MSDS.
10. All uncured sealant spills/splashes and tools should be cleaned immediately using **RESIBLOCK RESICLEAN.**

### FOR FURTHER INFORMATION OR TECHNICAL ASSISTANCE CONTACT RESIBLOCK LTD

Resiblock Ltd  
Resiblock House  
Archers Fields Close  
Basildon  
Essex, SS13 1DW

Tel: (+44) 01268 273344 Fax: (+44) 01268 273355  
email: [mail@resiblock.com](mailto:mail@resiblock.com)  
[www.resiblock.com](http://www.resiblock.com)



[www.paving.org](http://www.paving.org)  
Associate Members Of Interpave Ltd



Sponsors of  
The Institute of Highway Incorporated Engineers

Please note this summary is offered as a general guide only and does not replace the current published Application Guidelines which must be read prior to application together with the current Material Safety Data Sheet.